

SANITARY EQUIPMENT AND HYGIENIC ARTICLES

MERIDA sp. z o.o. • 53-015 Wrocław • Karkonoska 59

tel. 71 33 97 888 • fax 71 361 61 61 POLAND

internet: www.merida.com.pl • e-mail: sekretariat@merida.com.pl

Keeping MERIDA UNIQUE Devices Clean

Cleaning methods

Type of soiling	Mixture (dosage)	Process
Light soiling, fingerprints, oil/grease and plant-based stains	MERIDA LUXIN PLUS NMU101 10 ml / 0.5 l water MERIDA BŁYSK NMU002 Ready-to-use mixture	Apply a small amount of the solution or product onto a soft MERIDA POLISH SRL033 cloth and wipe the soiled surfaces. If excess product remains, remove it with a dry part of the cloth.
Heavy soiling, oils, grease	MERIDA SUPER BŁYSK NMU001 Ready-to-use mixture	Apply the ready-made solution onto a MERIDA POLISH SRL033 cloth and remove the soiling. Wipe the surface dry.
Limescale deposits	MERIDA SANITIN PLUS 15 ml / 0.5 l water MERIDA NANO SANITIN PLUS NML103 15 ml / 0.5 l water	Apply the ready-made solution onto a MERIDA POLISH SRL033 cloth and remove the soiling. Neutralize the surface with water and wipe dry.

Note

Do not use mixtures based on hydrochloric acid, bleaches, or chlorine, nor products in the form of cleaning milk, powders or scouring pastes, nor aggressive sponges such as those used for washing dishes.

Do not use other cloths, especially knitted/terry cloths (resembling a FROTE towel).

THE ONLY RECOMMENDED CLOTH IS MERIDA POLISH SRL033.

For cleaning devices from the MERIDA UNIQUE line, do not use strong acids and bases, or any substances containing chlorides, bromides and iodides. Using the substances listed above will cause permanent damage to the cleaned devices and will void any possibility of a warranty claim.

IF THE USER DOES NOT FOLLOW THE ABOVE RECOMMENDATIONS, MERIDA SHALL NOT BE LIABLE FOR ANY MECHANICAL DAMAGE.
